"ROMANTIC CAROUSEL"

MECHANICAL MUSIC BOX

AMK62

ROKR

WARNING:
The product is for people who include and over 14 years old.
Kids should assemble under the guidance of adults.

MAINTENANCE:
Keep the product away from the source of ignition and don't soak it into water.
Don't use chemical solvent like alcohol, ammonium hydroxide or cleaning agent to clean the product.
Use clean and soft fabric to clean the product. Polish the part edge with sandpaper.

Email: service@robotime.com

ROKR Facebook

store.robotime.com

Special attention in assembly.

Ensure the connection of gears running smoothly.

Wax the gray parts with remind.

Polish the parts with sandpaper.

Complete 2 same parts.

Printed side

Blank side

Step1

Step2

Perspective conversion

Parts List

*Due to customs policy in international shipping, the wax and glue may not be included. Please prepare them yourself.

Item	Movement	Screwdriver	Screw	Key	Big metal gasket	Small metal gasket	Metal stick	Crown	Wax	Sandpaper	Tape	Steel shaft
Number	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11	P12
Illustration												
Quantity	1	1	9	1	1	1	1	1	1	1	1	1





ROKR

Bottom view after installation.

1

D10 can be slightly raised to help assembly.

2

Rotating P5 and assemble it to P1.

P12

P5

P1

4

D5

Polish and wax the gray part.

x5

F5

F10

Scan for assembly video

D12 (Assistant tool)

Put D12 under the hole of wood disc, then insert F5 into the hole.

D4

D1

B2

B3 x5

Ensure the signs on the stick matching the arrow.

Ensure C10 and C11 in the right place.

Wind up the key and ensure gray part rotate smoothly.

Assembly diagram

5

F1

F14

F13

F12

F3

C12

F2

C12

F7

F4

x5

Insert C12 at last.

Do not assemble the horses together at the same time, please follow the steps ①—⑥.

2

F6

F9

F11

3

D6

4

Adjust F6 to the angle as shown, there are another 4 F6's angles are shown on Step⑤. All of 5 pieces of F6 's angle are different.

5

Scan for assembly video

F8

Ensure the sticks in the holes all the time.

6

Repeat 6 steps and finish the horses' part.

Adjust the other 4 pieces of F6 as shown.

2 3 4 5

Picture of top part assembly

Wind up the key on bottom after assembled and ensure it rotating smoothly.

Assembly diagram

6

B5

B15

B19

B2

B19

B2

The upper surface of B19 is aligned with indentation on the long stick.

The arrow corresponds to the mark on the long stick.

B9

E3 x12

C7

D8 x5

D7 x5

C1 x5

The arrow corresponds to the mark on the long stick.

B4

P8

P11

Stick double-sided tape here.

Stick together as shown.

90°

Fold the 4 black parts 90°as shown.

B7

P8

B11

B10

B20

The arrow corresponds to the mark on the long stick.

B8

7

B14 x10

B17

x10

C9

e1 x2

D12 (Assistant tool)

Easy assembly way

x10

E2 x5

Completed