INSTRUCTION

Haunted Candy House

• DG186



Pictures for reference only. Please subject to our existing products.

Scan the QR code or go to Community.robotime.com to discover DIY ideas, quick tips & WIN free kits

Assembly tips

Put small parts into the bag to prevent loss.

Remove the part by pressing its back to reduce burrs.

Polish the edges with sand-paper if there are burrs on pieces or it' s hard to insert.

Icon Illustration

Use double-sided tape

Special attention in assembly

Remove protective film

Use double-sided adhesive dot

Perspective changed

Step 1

Step 2

Printed side

Blank side

Part P19 in Bag No. 3

Tips of assembling

1. All the dimension in the instruction is shown in millimeter.
2. The included double-sided tape is an auxiliary tool for sticking. Glue needs self-preparation.
3. Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
4. Only the tool icon appears in the assembly step.
5. Check if the light parts are securely welded.

Part number illustration

Refer to the part number paper, find the piece, and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with (P))

Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.

Brief Introduction

WARNING:

01.Not suitable for children under 3 years old.
02.The product shall only be used with a transformer for product or a power supply for it.
03.The product shall be used with the power supply supplied, if the transformer is supplied with the product.
04.The transformer or power supply is not a toy or model.
05.Misuse of transformer can cause electrical shock.
06.The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
07.Do not connect the wire to output socket.
08.The product is not to be connected to more than the recommended number of power supplies.
09.If the product contains motor, motor may be a hot component. Do not touch it to avoid burns while operating.
10.This product is only to be connected to equipment bearing either of the following symbols: or
11.This product does not need liquid cleaning, and please clean the product with clean soft cloth.
12.The instruction must be retained since it contains important information.

ATTENTION:

01.Children should be accompanied by adults while assembling.
02.This product contains small parts. Please use it carefully to avoid accidental ingestion and choking.
03.Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
04.This product needs to be made with auxiliary tools. Please select it reasonably to avoid injury.
05.Please carefully cut the parts and make sure they are firmly pasted when using glue.
06.Please install the electronic components correctly and test whether the circuit is normal after completion.
07.Please don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
08.Please clean the product with clean soft cloth, and sand the board burr lightly with sandpaper.
09.Please keep the product away from flammable substances and humid environments to prevent damage.
10.The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
11.The Purple-hat Pumpkin, Transparent Candy, and Faceless Ghost are made of resin with luminous material. They contain phosphorescent powder that absorbs sunlight or UV light, allowing them to glow in the dark. The longer they are exposed to light, the longer the glow will last.

Electronic Parts Assembly Guide

Light test



Self-prepare a Type-C cable. Input power supply: 5V 500mA Note: Over-current protection provided, adapters ≥ 500mA are acceptable.

Check if the light is on.

If there are abnormalities, please contact customer service. If not, remove the electronic parts for later use.

Storage basket

Material list:

Board

Paper-cutting



Shelf

Material list:

Board

Paper-cutting





Counter

Material list:

Board

Paper-cutting





Closet

Material list:

Board

Paper-cutting

Other parts





Door

Material list:

Board

Paper-cutting

Other parts





Chandelier

Material list:

Board

Paper-cutting

Other parts





Sign & Doorplate

Material list:

Board

Paper-cutting




Material list:
Decoration
Fence
Fence
Fence

Rollercoaster Rollercoaster Rollercoaster Rollercoaster Rollercoaster Rollercoaster



























Scan to Find Your Perfect **Display Box**

Keep Your Miniatures Clear
Safe & Stackable

1 Dust-Free

2 Hackable

MANUFACTURER:
Rolanbao Inc. Company Ltd.
AFTER-SALES SERVICE CONTACT:
mail:rolife@rolife.com

Rolife

Designed in China
www.rolanbao.com
All Rights Reserved
©2021-2022