Rolife

INSTRUCTION

Twinkling Christmas Eve

DWZ03

The picture is for reference only.

Scan the QR code or go to Community.robotime.com to discover DIY ideas, quick tips & WIN free kits

Assembly Tips



Remove the tape from the side with the tip of the tweezers.



Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.



Push upwards with the tip of the tweezers to remove the floor.



Use the end of the tweezers to remove the connecting nail or assemble small parts.

01 Notice

WARNING:

- Not suitable for children under 3 years old.
- The product shall only be used with a transformer for product or a power supply for it.
- The product shall be used with the power supply supplied, if the transformer is supplied with the product.
- The transformer or power supply is not a toy or model.
- Misuse of transformer can cause electrical shock.
- The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
- Do not connect the wire to output socket.
- The product is not to be connected to more than the recommended number of power supplies.
- If the product contains motor, motor may be a hot component. Do not touch it to avoid burns while operating.
- This product is only to be connected to equipment bearing either of the following symbols: ⧈ or ⟐
- This product does not need liquid cleaning, and please clean the product with clean soft cloth.
- The instruction must be retained since it contains important information.

NOTICE:

- Children should be accompanied by adults while assembling.
- Please keep the product away from flammable substances and humid environments to prevent damage.

02 Icon

Please secure parts as shown in case of any parts loosening:

Use double-sided adhesive dot	Use long-strip adhesive tape
Special attention in assembly	Perspective changed
ⓧ2 Complete 2 same parts	Force point
① Step 1	② Step 2

03 Switch box instructions (P2)

❶ Switch

❷ Power-on


Control A1, A2
Control B
A1
A2
B

Touch switch
(Long press to adjust the brightness.)

Input power supply: 5V ⎓ 500mA
Note: Over-current protection provided, adapters ≥ 500mA are acceptable.

04 Data cable instructions (P1)

❶ Connect to power Charger needs self-preparation



Dual Type-C cable
Included in the product

Single-ended Type-C cable
Self-preparation

❷ Multi-house play[It is recommended that each power supply (not less than 5V 2A) connected to no more than 9 houses.]



05 Assembling steps






(DWZ03-K)
(DWZ03
2)





When all four decorative covers are assembled, use tweezers to push the covers out from the back.


(DWZ03
2)
(DWZ03
2)
43.3DWZ03.101
43.3DWZ03.102

Remove useless round parts on the paper.




43.3DWZ03.104
(Light part)

See "03 Switch box instructions" on Page 1.

Avoid the bayonet point before installing the wires.

Please check the following two situations before assembling:


43.3DWZ03.103












08
DWZ03 4
K4














12
DWZ03 6
K5




13
DWZ03 6
K7


14
DWZ03 6
DWZ03 2
M5



















Assemble the same way





Assemble the same way







06 Add some other tricks

01 Adjustment of the position of the switch box and wallpaper.







02 Ceiling light assembly



P4
(Light part)




Under the roof for 1 house

Purchase it separately
Under the floor for 2 or more houses


(Connecting part)




Input power supply: 5V ⎓ 500mA
Note: Over-current protection provided, adapters ≥ 500mA are acceptable.

Cable in the box

03 Dust-proof doot assembly



Purchase it separately



04 Expand your house kit





MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd

AFTER-SALES SERVICE CONTACT:
service@robotime.com

Rolife

49.1DWZ03.100