ROWOOD

49.1TGA07.100.B

Sakura Pavilion


• TGA07 •


ICON ILLUSTRATION

- Printed side / Colored side
- Blank side / Colorless side
- Step 1
- Step 2
- Perspective changed
- Remove protective film
- Special attention in assembly
- Complete 4 same parts
- Assembly tips
- Use double-sided tape
- "+" means the part has spare ones


NOTICE:

- Children should be accompanied by adults while assembling.
- Please keep the product away from flammable substances and humid environments to prevent damage.
- The product contains small parts. Adults should guide and supervise children in the correct use of the product to prevent ingestion or choking.
- Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
- Take off the pieces from the board according to each step before assembling and place them properly in case of missing.
- Please don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- Please clean the product with clean soft cloth, and sand the board burr lightly with sandpaper.
- This product needs to be made with some auxiliary tools. Please select it reasonably to avoid injury.
- Please carefully cut the parts and make sure they are firmly pasted when using glue or tape.
- If parts break, repair them with an appropriate adhesive.
- There are letters on some parts as shown and assemble them together with the same letters.
- There is a little difference between several parts and the pictures on instruction, subject to parts number.
- There are spare parts on wooden boards.
- The instruction must be retained since it contains important information.







6




7



8




9




10





11




12








13




14

15



16



17

